

## Attaching the back support to the *my move* WC



**1.** Place the backrest on the existing fastening option



**2.** and tighten firmly with an Allen key.



**3.** Align in depth by turning



**4.** and tighten firmly with an Allen key