

Geberit wireless push button for electronic flush activation,
battery operated, wireless, 2 volumes



Intended use

- For manual remote triggering of Geberit Sigma concealed cisterns 12 cm above electronic toilet control

Features

2-volume flush can be activated
- Battery operated

Scope of delivery

- 2 AAA 1.5V alkaline batteries
- Mounting hardware

Make: Geberit

Type: Toilet control

Item no.: 505425